

## Instructions for sublimating the Seat Cushion JP Part # SUBSCBK

### Items recommended for best printing results:

- Flat Heat Press
- Heat Tape or Spray Tack
- Vapor Foam
- White Copy Paper or Teflon Sheet

Set the temperature of the press to 400 degrees.

Print transfer using the polyester setting if using a Power Driver.

Cut a circle of Vapor Foam 13½" in diameter. Unzip the seat cushion and place the circle of Vapor Foam inside, on top of the original white foam. It may be easier if you take out the original white foam and fold them both in half before reinserting. (Unfold both together to help keep them centered, Vapor Foam up, nearest the white side of the cushion).

Adjust your heat press for very, very light pressure. Place the seat cushion under the heat platen with the white side up. Make sure the heat platen will not make contact with the nylon zipper or handle of the cushion. Do not close the press completely, only enough to engage the timer and make contact with the seat cushion.

Press for 40 – 50 seconds.

Open the press slowly after the timer goes off so the transfer doesn't shift and blur the image. Remove the cushion from the press, take off the transfer and protective sheet, (or Teflon), and immediately remove the Vapor Foam from inside.