

SubliCotton II SUBPTSD8511 / SUBPTSD1117

INFORMATION & INSTRUCTIONS

General use

Cotton, synthetics and blends in both light and dark colors.

Printing Equipment

SubliCotton II works on the full range of inkjet printers using any of the common brands of sublimation ink.

Printing

Using SubliJet IQ or Artainium Inks:

- Use the same settings as for other sublimation transfers.
- Adjust saturation levels as necessary for your image.
- If when printing, your text becomes jumbled you will need to convert the text to a bitmap. In Corel Draw select the text, click on the "Bitmap menu" and click "Convert to Bitmap".

Heat Press Set-Up

- Trim away the unprinted area around the image - for best results we recommend a plotter-cutter with appropriate software.
- Remove backing paper from transfer film.
- Position imaged transfer film on garment with printed side face up.
- Cover transfer film with silicon paper or Teflon sheet.

On to cotton/cotton blends:

Press at 385°F (196°C) using **medium pressure** for 25 seconds.

On to synthetic fabrics:

Synthetic fabrics: 365°F (185°C) using **medium pressure** for 15-20 seconds.

Washing Instructions

- Always turn textile inside out before washing.
- **Recommended:** Machine wash in cold water.
Optional: Machine wash in warm water (40°C).
- Use mild detergent. Do not use harsh or bleaching materials.
- **Recommended:** Hang dry
Optional: Tumble dry with cool or warm air setting. Do not use fabric softeners.
- After washing we recommend turning shirt inside out and ironing the image from the back.
- Do not Dry Clean.