

## Cleaning Laser Optics

The Laser Optics Cleaning tissues, solution and dusting spray can be used to clean the Optics of your laser engraver.

Regular cleaning will ensure reliability and peak performance.

- Remove all debris from the optics with the **Precision Dusting Spray** being careful to keep the spray away from your face and skin.
- Fully wet down the optics with some **Laser Optics Solution**. The spray action of the laser Optics solution will help remove debris and residue.
- Using light pressure, wipe across the surface in one direction only with a **Laser Optic Tissue**, using a clean area of the tissue or a new one to continue the cleaning process.